




**IMPAKT | MAGNETIC NUT DRIVERS****IMPAKT | LLAVE DE VASO MAGNÉTICA****IMPAKT | BUSSOLA DI SERRAGE MAGNETICA**




Socket for Impact wrench - for extreme socket driving applications.

Llaves de vaso: Uso sobre taladro a percusión para responder a las dificultades extremas de atornillado.

BUSSOLA: uso su avvitatore a impulsi, per rispondere alle esigenze di avvitatura estrema.

Sockets  
Casquillos  
Portapunte

1152192	EAN	Ø	L	QTY PCB	
11521920600	3221910899486	6	45	1	1
11521920800	3221910899493	8	45	1	1
11521921000	3221910899509	10	45	1	1
11521921100	3221910899516	11	45	1	1
11521921200	3221910899523	12	45	1	1
11521921300	3221910899530	13	45	1	1

**CLASSIC | MAGNETIC NUT DRIVERS****CLASSIC | LLAVE DE VASO MAGNÉTICA****CLASSIC | BUSSOLA DI SERRAGE MAGNETICA**

Nut driver for conventional drill/driver.

Llave de vaso: uso sobre atornillador tradicional.

Bussole: uso su avvitatore tradizionale.

Sockets  
Casquillos  
Portapunte

1150192	EAN	Ø	L	QTY PCB	
11501920400	3221910115272	4	38	1	3
11501920500	3221910115289	5	38	1	3
11501920600	3221910115296	6	38	1	3
11501920700	3221910115302	7	38	1	3
11501920800	3221910115319	8	38	1	3
11501920900	3221910115326	9	38	1	3
11501921000	3221910115333	10	38	1	3
11501921100	3221910115340	11	38	1	3
11501921200	3221910115357	12	38	1	3
11501921300	3221910115364	13	38	1	3



**SET | 6 NUT DRIVERS**



Nut driver for conventional drill/driver. Ø 6-8-8-10-12-13 mm

**ASS | 6 LLAVES DE VASO**




Llave de vaso: uso sobre atornillador tradicional. Ø 6-8-8-10-12-13 mm

**ASS | 6 BUSSOLE**

**11501920001**

3221910899462

QTY	PCB
6	1



Bussole: uso su avvitatore tradizionale. Ø 6-8-8-10-12-13 mm

**UNIVERSAL SOCKET**



Universal socket - the perfect tool to replace conventional spanners/pliers/sockets.

**GATOR GRIP**




el casquillo universal, la herramienta indispensable para reemplazar llaves, pinzas y casquillos tradicionales.

**GATOR GRIP**

**11501420002**

3221910820985

QTY	PCB
3	6



La bussola universale, l'utensile indispensabile per sostituire chiavi pinze et bussole tradizionali.

**4 SOCKETS & 1 BITHOLDER**



Assortment of 4 sockets Ø 6-8-10-13 mm + 1/4" sockets bitholder - for use with conventional drill/drivers.

**4 LLAVES DE VASO + 1 PORTA-VASOS**




Un surtido de 4 llaves de vaso Ø 6-8-10-13 mm con el porta-vasos para utilización en el atornillado tradicional.

**4 BUSSOLE + 1 PORTA BUSSOLE**

**11501420001**

3221910207830

QTY	PCB
5	1



Assortimento di 4 bussole Ø 6-8-10-13 mm con porta inserti 1/4" per utilizzazione su avvitatore.

**IMPAKTOR | BIT HOLDER**



Bit holder with Double Torsion zone combined with use of Impaktor bits = 'Tri Torsion' system.

**IMPAKTOR | PORTAPUNTAS**



La combinación de la doble zona de torsión situada en el portapuntas y que se ajusta a la punta Impaktor constituye el sistema "Tri-Torsión".

**IMPAKTOR | PORTA INSERTI IMPULSI**

**11521320001**

3221910899660

QTY	PCB
1	1

La combinazione di due zone di torsione situate nel porta inserto e delle celle che equipaggiano l'inserto Impaktor lo rendono un sistema "Tri-Torsion".