

## FORETS À POINTER NC COURTS

## NC-ANBOHRER KURZ




## PUNTE A CENTRARE NC CORTE

## Coupe à gauche Linksschneidend Elica sinistra



magafor standard			$\alpha$	90°	90°	120°
D	L	l		magafor 192	TiN 0992	magafor 193
h6	$\pm 1$	+1				
3,0	50	10	€	25,00	€ 30,00	€ 25,00
4,0	52	12		30,00	35,00	30,00
5,0	60	15		35,00	40,00	35,00
6,0	66	20		40,00	47,50	40,00
8,0	79	25		45,00	55,00	45,00
10,0	89	25		50,00	62,50	50,00
12,0	102	30		60,00	75,00	
16,0	115	35		95,00	117,50	

## Angle 60° Winkel 60° Angolo 60°





magafor standard				$\alpha$	60°
D	L	l	T*	magafor 191	TiN 0991
h6	$\pm 1$	+1			
4,0	52	12	0,8	€ 45,00	50,00
5,0	60	15	0,9	47,50	52,50
6,0	66	20	1,0	50,00	57,50
8,0	79	25	1,3	52,50	62,50
10,0	89	25	1,6	55,00	67,50
12,0	102	30	2,0	60,00	75,00
16,0	115	35	3,0	90,00	112,50
20,0	131	40	3,5	150,00	185,00

\*T = angle Winkel Angolo 120°

**Extra courts**  
**Extra kurz**  
**Extra corta**



$\alpha$		<b>90°</b>		<b>118°</b>	
D <sub>h7</sub>	L	$\ell$	$\ell$	Classic <b>19-A</b>	Classic <b>19-B</b>
inch	mm	± 1	+ 1	€	€
1/8"	3,17	32	9,5	9,00	9,00
3/16"	4,76	35	12,5	10,00	10,00
1/4"	6,35	38	16	11,75	11,75
5/16"	7,93	38	16	12,50	12,50
3/8"	9,52	51	25,5	14,00	14,00
7/16"	11,11	51	25,5	17,25	17,25
1/2"	12,7	51	25,5	20,75	20,75
5/8"	15,87	57	28,5	28,25	28,25
3/4"	19,05	57	28,5	57,50	57,50
7/8"	22,22	64	32	77,50	77,50
1"	25,4	64	32	85,50	85,50



**FORETS À POINTER NC**  
**NC-ANBOHRER**  
**PUNTE A CENTRARE NC**

**Queue cône Morse**  
**Morse Kegel Schaft**  
**Cono Morse**



$\alpha$		<b>90°</b>		<b>120°</b>	
D	L	$\ell$ 1	$\ell$ 2 MORSE	magafor <b>198</b>	magafor <b>1906</b>
h10	± 1	+ 1	+ 1 N°	€	€
10,0	130	25	64 1	84,50	95,50
12,0	130	30	64 1	88,50	98,50
16,0	148	35	68 2	109,00	122,00
20,0	148	40	68 2	130,00	145,00
25,0	171	45	72 3	179,00	198,00

